


Frame Number and Face

The frame number and face for each tool is displayed in the bottom right section of the [tool tracking utility](#), under the heading **Tracking Information**.



Frame: The number of frames since the last system reset.

Face: Indicates which face is being tracked on a multi-faced tool. On a single-faced tool, ToolBox will report that face 1 is being tracked.

Return to...

- > [Tool Panel Display](#)
- > [Tracking Tools](#)

Related Topics:

- [Tracking Tools](#)
- [Position and Orientation](#)
- [Transformation Errors and Warnings](#)
- [Marker Information](#)
- [Tool Tracking Utility](#)