

MODEL: 354010 - CANCEL STATION



FEATURES

- One (1) Cancel button
- Flexible programming for cancellation of calls in a room
- Continuous supervision of station
- Plug-in connectors for easy service
- Optional antimicrobial Bio-seal to cover buttons and allow for easy disinfecting of the station

SPECIFICATIONS

POWER REQUIRED: 6.25mA @18V

WEIGHT: 0.18 lbs (0.80 kg)

SIZE: W: 3.13" (7.95 cm)

H: 4.25" (10.80 cm)

D: 0.50" (1.27 cm)

HOUSING & FINISH: High-impact molded Cylcoloy 2950 UL 94-5VB;
light grey faceplate

CONTROLS: One (1) Cancel button

TERMINATIONS: Plug-on connector

BACKBOX REQUIREMENT: 1 device, Non-gangable, 3 1/2" deep, (i.e. Raco 561, Steel City 58371, ¾ R, or UL recognized equivalent metal backbox)

CERTIFICATION: UL/C-UL 1069, FCC Part 15 Class B, IEC60601-1 and IEC60601-1-2, CE Mark (LVD) (all Pending)

DESCRIPTION

The Cancel Station can be programmed to cancel some or all call priorities placed from a room. The Cancel Station is used in situations where the cancel button on the patient station or button station is too difficult to reach. It is normally located by the door just inside the patient room. The Cancel Station is connected to its associated corridor light or room controller and is continually supervised.

Rauland-Borg Corporation

Architects and Engineers Specifications available on disc. Specifications subject to change without notice.

USA • 800-752-7725 • Fax 847-679-4106
CANADA • 905-607-2335 • Fax 905-607-3554
www.rauland.com

MODEL #354010
05/2008

©Copyright 2008 Rauland-Borg Corporation / Printed in USA