

MODEL: R5K SINGLE PATIENT STATION VISUAL





FEATURES

- One (1) DIN receptacle for call cord or pillow speaker for tone/visual system
- (1) Call Assurance LED
- · Annunciates cord-out
- Cancel button for station or room-wide cancel function
- · Optional antimicrobial Bio-seal to cover Cancel button
- · Continuous supervision for station presence
- · Surface mount for easy installation
- · Designed for use with single gang backbox

R5KPS1V

SPECIFICATIONS

Power Requirements: 15.5V DC @ 3 mA

Weight: 82 g (2.8 oz)

Size: W: 7.8 cm (3.14")

H: 10.96 cm (4.31")

D: 2.38 cm (0.94")

Housing and Finish: Polycarbonate ABS, UL 94-5VA; light

gray faceplate.

Controls/Indicators: One (1) DIN receptacle, One (1) Call

Assurance LED, and One (1) Cancel button.

Backbox Requirement: Surface mountable; compatible with European, North American, South American single gang box.

Terminations: Plug on connector, CAT 5 and CAT 6 com-

patible

Certifications: Designed for compliance to ANSI/UL 1069, IEC 60950, CE, RoHS / WEEE Compliant. Assembled in a

U.S. FDA Registered facility.

DESCRIPTION

The R5KPS1V provides one DIN receptacle for use in a tone/visual system. Call cords are typically used to initiate a call although pillow speakers can also be used to place a call along with providing entertainment audio and control.

The station is continuously supervised for station presence. A "Trouble" message will also annunciate at the covering console(s) if the station is removed from the system or becomes non-functional.

